

# NANOJET FOGGING MACHINE



ROTO 360°



“For effective application of disinfectants,  
biocides, fungicides and pesticides.”

In Hospitals, Labs, Pharmaceutical Industries, Clean Rooms, Healthcare,  
Biotech & Tissue Culture Labs, Dairies, Food Processing Areas & Hatcheries etc.

## NANOJET FOGGING MACHINE

NanoJet Fogging Machine from Medix Medical is the most advanced ULV Fogger for aerial disinfection.

NanoJet is used predominately for the application of disinfection at Hospital, Laboratories and pharmaceutical industries, clean rooms, health care, biotech & tissue culture labs, dairies, food processing area and hatcheries etc. It also used for application of biocides, fungicides and pesticides.

NanoJet generates a fog or mist formed by ultra low volume uniform sub-micron size liquid particles. Liquid formulation can be applied in concentration of 2%-90% & at a flow rate of 1-5 liters per hour adjustable using upgraded flow control mechanism.

If required NanoJet will come with digital timer makes fogging system hassle-free. NanoJet runs on high speed FHP motor that provide the maximum thrust spray. Coupled with advanced thrust design Air-jet nozzle.

This fogger achieves fog thrust of >50 feet. This model is portable & can be carried or moved easily. Entire body and internal parts are made of material that resist corrosion and chemical attack. The storage tank from 6 Litre Ss304. Sufficient to cover an area of > 20,000 cubic feet. The Sturdy and most durable NanoJet machine is the ideal solution to meet all our fogging needs.





## FEATURES

- Dry Fog, Uniform sub-micron size liquid particles (Non Wetting)
- Adjustable flow rate of 1-5 Litres per hour
- Space treatment >20,000 cubic feet
- Fog spread up to 50 feet distance & 25 feet height
- Nozzle Assembly - Non clogging design with SS 304 material
- Advance thrust design for Air Jet Nozzle
- High Speed UL approved FHP motor for maximum thrust spray
- Body & internal parts that resist corrosion and chemical attack as well as shock proof
- Intake air filter - Three Stage uniquely designed filter for dust & fog separation
- Digital Timer to set the fogger [Optional]
- Sturdy, most durable and maintenance free



Nozzle



Intake Filter



Portable Body



Digital Timer (Optional)



SS 304 Tank (6Ltr)

## CONSTRUCTION MATERIAL USED

Housing Engineering Plastic

(Chemical and corrosion Resistant, Shock proof)

Nozzle Assembly SS 304 Grade, Air jet nozzle with advanced thrust design

Strainer & All Hardware SS 304 Grade

Nipple SS 304 Grade

Flow Control Mechanism SS 304 Grade

Tubing Silicone Grade suitable for Medical grade equipment

## TECHNICAL SPECIFICATION

**Power Supply:** 230V AC 50 Hz

**Aerosol:** Submicron Size (Non Wetting)

**Noise Level:** <70 db @ 1 meter

**Spread and Reach:** 50 feet Distance / 25 feet height

**Space Treatment:** 20,000 cubic feet

**Intake Airflow:** Dust & fog separation layer

**Storage Tank Capacity:** 6.5 Ltr

**Dry Weight:** 7-8 Kg (Portable)

**Liquid Flow Rate:** 1 ~ 3 Ltrs./Hr.(Adjustable)

## 360° Rotatable Stand

### ■ 360 Rotatable Stand

Presenting the all new, Roto360 Turn Table (an accessory), A 360° Rotating Device from IFS that vastly improves the performance of Nanofog 30 series foggers.

#### Sailent Features

- 360A 360° Rotation increase area coverage almost thrice than, without it.
- Help fog spread in all direction & reach every corner of the space.
- Ensures 'equal' distribution of the fog into the air.
- Prevent condensation of fog particles due to the movement.
- Saves time as effectively treat the area in less time.
- NIL maintenance & trouble free operation.







+91 9302 778 762  
+91 9111 429 222



export@mediequipbazar.com  
info@mediequipbazar.com



+91 9302 778 762  
+91 9111 429 222



## MANUFACTURING UNIT

Plot No. 23-B, Badiyakhedi  
Industrial Park Phase I,  
Badiyakhedi, Sehore, M.P.,  
India - 466 001



### MANUFACTURING UNIT

Plot No.-40, KI Ansal  
Green, Kolar Road  
Bhopal-462042



### MANUFACTURING UNIT

Plot No. - 79, Commercial  
Shade, Near D-Mart,  
Bhopal, 462042



[www.mediequipbazar.com](http://www.mediequipbazar.com)



### REGISTERED OFFICE

#### MEX ENTERPRISES

ISO 13485 :2016 & ISO 9001 :2015 Certified Company

Plot No. 50/1B-50/2B, Rajharsh Colony,  
Near CI Square Shopping Mall, Kolar Road,  
Bhopal, M.P.-462042

### SALES OFFICE

#### MEX ENTERPRISES

ISO 13485 :2016 & ISO 9001 :2015 Certified Company

Building Name - Classic's, T-1895/1,  
Upper Ridge Road, Karol Bagh,  
New Delhi - 110005

### SALES OFFICE

#### MEX ENTERPRISES

ISO 13485 :2016 & ISO 9001 :2015 Certified Company

House No.-10/806, Shivanand Nagar,  
Jhanda Chowk, Raipur CG-492008